


Computer Vision & Multimedia Analysis Course

Lab 3: Tracking

Niccolò Bisagno niccolo.bisagno@unitn.it




Feedback





Feedback





Feedback

- * Material before lectures
- Real-world applications examples
- More challenging suggestions/material



What's up today (and Monday)

- Good Features to Track + Lucas Kanade optical flow
- Meanshift/Camshift algorithm
- * Kalman filter



Good Features to Track

* For each candidate point, compute:

$$Z = \begin{bmatrix} \sum_{W} J_{x}^{2} & \sum_{W} J_{x} J_{y} \\ \sum_{W} J_{y} J_{x} & \sum_{W} J_{y}^{2} \end{bmatrix}$$

- * J_x and J_y are the gradients evaluated on the point in x and y direction within W (nxn window)
- * A good feature point is where the smallest eigenvalue of Z is larger than a specified threshold
- * In practice, it highlights corner points and textures



Lucas-Kanade optical flow estimation

- * Two-frame differential method for optical flow estimation developed by Bruce D. Lucas and Takeo Kanade (1981)
- * Consider $u=[u_x, u_y]$ in frame I and $v=[v_x, v_y]$ in frame J
- * The goal is to find **d** that satisfies **v=u+d** such as I and J are similar (translational model)
- Because of the aperture problem, similarity must be defined in
 2D
- * d is the vector that minimizes

$$\epsilon(d) = \epsilon(d_x, d_y) = \sum_{x=u_x - \omega_x}^{u_x + \omega_x} \sum_{x=u_y - \omega_y}^{u_y + \omega_y} (I(x, y) - J(x + d_x, y + d_y))^2$$

 $* \omega$ is the integration window



GFF+LK tracking

Use GFF to detect and select good Features

Track detected feature using LK optical flow



Exercise

Part 1

- Track features in the environment using
- * corners, status, err = cv2.calcOpticalFlowPyrLK(prev_fr ame, frame, prev_corners, None)

Part 2 (optional)

Draw trajectory of tracked points




Exercise


Part 3

- * How to avoid losing features after some time?
- * Re-detect features using GFF



















- * RGB to HSV image conversion
- Manually select Region Of Interest (ROI)
- Calculate histogram of ROI
- Back projection of the histogram
- * Tracking



Kalman filter

- * Inside the Virtual Machine (or in your programming environment)
- * Go to this link and download the file
- https://github.com/nick1392/kalman




Kalman filter

$$X_k = A_k X_{k-1} + W_{k-1}$$
$$Z_k = H_k X_k + V_k$$

- *x_k is the current state
- $*x_{k-1}$ is the previous state
- *A_k is the state transition matrix
- *w_k is the process noise
- *z_k is the actual measurement
- *H_k is the measurement matrix
- *v_k is the measurement noise



Kalman filter





Kalman filter applied on mouse motion

- * Motion equation: $P_t = P_0 + V * t$ $X_k = A_k X_{k-1} + W_{k-1}$ $Z_k = H_k X_k + V_k$
- $*x_k$ is the current state —> a vector with the position and velocity
- $*A_k$ is the state transition matrix —> matrix that describe the system, in our case the motion equation
- $*H_k$ is the measurement matrix —> determined by the current measured position of the mouse
- $*z_k$ is the actual measurement —> used to compute the "posteriori"



Transition matrix

 $v_{-y_{t+1}} = v_{t_t}$



Exercise

 Insert acceleration in the transition matrix of the Kalman filter

$$x_{t} = x_{0} + v_{x} * t$$

$$x_{t} = x_{0} + v_{x} * t + \frac{1}{2} a_{x} * t^{2}$$



Transition matrix

$$X = [x, y, v_x, v_y, a_x, a_y]^t$$

$$x_{t+1} = x_t + v_x_t + 0.5 a_x_t$$

$$v_{t+1} = y_t + v_y_t + 0.5 a_y_t$$

$$v_{-x} = v_{-x} + a_{-x} + a$$

$$v_{y_{t+1}} = v_{t_t} + a_{t_t}$$

$$* a_x_{t+1} = a_x_t$$

$$* a_y_{t+1} = a_y_t$$